



When wiring 2 amplifiers to 1 subwoofer, you need to level match the amplifiers to make sure they are both putting out the same signal. This can be done by measuring the AC voltage output on the amps with a volt digital volt-meter. Adjust the gains so that that both amplifiers are putting out the same voltage within 0.1 volts of each other. You must use the same amplifiers with this scenario.